

POISON

KEEP OUT OF REACH OF CHILDREN
READ SAFETY DIRECTIONS BEFORE OPENING OR USING

TITAN

Bifenthrin

100 Termiticide & Insecticide

ACTIVE CONSTITUENT: 100g/L BIFENTHRIN

SOLVENTS: 650g/L LIQUID HYDROCARBONS

For the protection of structures from subterranean termite damage and for the control of termites and a range of other urban pests as specified in the directions for use table.

IMPORTANT: RESTRICTED CHEMICAL PRODUCT ONLY TO BE SUPPLIED TO, OR USED BY, AN AUTHORISED PERSON.

IMPORTANT: READ THOROUGHLY BEFORE OPENING OR USING THIS PRODUCT.

APVMA Approval No.: 57837/0207

Pack Size: 1L, 5L, 20L, 200L



TITAN AG Pty Ltd

3/14 Narabang Way, Belrose NSW 2085

Telephone 02 9986 2943 Fax 02 9986 2945

www.titanag.com.au

IN A TRANSPORT EMERGENCY

DIAL 000

POLICE OR FIRE BRIGADE

TRANSPORT AND HANDLING
NOT A DANGEROUS GOOD
ACCORDING TO THE AUSTRALIAN
DANGEROUS GOODS (ADG) CODE
FOR TRANSPORT BY ROAD AND RAIL.

DIRECTIONS FOR USE

Restrictions: DO NOT use at less than indicated label rates.
 DO NOT apply to soils if excessively wet or immediately after heavy rain, to avoid run-off of chemical.
 DO NOT use in cavity walls (except for direct treatment of nest or via certified cavity infill reticulation systems).

SITUATION	PEST	STATE	RATE per 10L	CRITICAL COMMENTS
External Areas and Surrounds of Domestic, Commercial, Public and Industrial buildings and structures	Ants, Cockroaches, Mosquitoes, Fleas, Flies, Ticks (excluding the paralysis tick <i>Ixodes holocyclus</i>) (Adults and Nymphs)	ALL STATES	500-100mL	On non-porous surfaces apply as a coarse spray at the rate of 1L of emulsion per 20m ² . When treating non-porous surfaces do not exceed the point of run-off. On porous surfaces or use through power equipment, spray at the rate of 1L emulsion per 10m ² . When treating porous surfaces do not exceed the point of run-off. Use the higher rate in situations where pest pressure is high, when rapid knockdown and/or maximum residual protection is desired. The lower rate may be used for follow-up treatments. To control ants apply to trails and nests. Repeat as necessary. To control fleas and ticks apply prepared emulsion to outside surfaces of buildings and surrounds including but not limited to foundations, verandahs, window frames, eaves, patios, garages, pet housing, soil, turf, trunks of woody ornamentals or other areas where pests congregate or have been seen. To control flies and mosquitoes apply prepared emulsion to surfaces where insects rest or harbour. Reapply as necessary. For perimeter treatments apply the prepared emulsion to a band of soil or vegetation two to three meters wide around and adjacent to the structure. Also treat the foundation of the structure to a height of approximately one metre. Use a spray volume of 5 to 10L per 100m ² . Higher volumes of water may be needed if organic matter is present or foliage is dense.
	Papernest Wasps		50mL	Apply prepared emulsion to the point of run-off directly to the papernest ensuring thorough and even coverage. When all adult wasps have been knocked-down the nest may be safely removed from the structure.
	Spiders		25-50mL	Use the higher rate in situations where pest pressure is high, when rapid knockdown and/or maximum residual protection is desired. Pay particular attention to protected dark areas such as cracks and crevices, under floors, eaves and other known hiding or resting places. For overall band surface spray, apply as a coarse, low pressure surface spray to areas where spiders hide, frequent and rest. Spray to the point of run-off using around 5L of spray mixture per 100m ² and ensuring thorough coverage of the treated surfaces. For crack and crevice treatment use an appropriate solid stream nozzle. For maximum spider control use a two part treatment: 1. Crack and crevice 2. Overall band spray of surfaces
Domestic, Public, Commercial and Industrial areas	Subterranean Termites	ALL STATES except TAS.	Refer to Table A	Refer to Table B.

TABLE A: TITAN Bifenthrin 100 Termiticide & Insecticide use rates for the control of Subterranean Termites

SITUATION	All areas SOUTH of the Tropic of Capricorn (except TAS,)		All areas NORTH of the Tropic of Capricorn	
	RATE/100L	Expected Protection Period*	RATE/100L	Expected Protection Period*
Pre-Construction Barriers Under slabs and under suspended floors with less than 400mm crawl space	1L	At least 10 years	1.5L	5 years
			1L (Note 1)	4 years
	500mL	10 years	750mL (Note 1)	3 years
			500mL (Note 1)	2 years
Perimeter Barriers For new and existing buildings	1L	At least 10 years	1.5L	5 years
	500mL	10 years	1L	4 years
	250mL	3 years	750mL	3 years
			500mL	2 years
Post-Construction Barriers Under slabs and under suspended floors with less than 400mm crawl space	1L	At least 10 years	1.5L	5 years
			1L	4 years
	500mL	10 years	750mL	3 years
			500mL	2 years
Reticulation Systems Perimeter and/or service penetration treatment only	1L	At least 10 years	1.5L	5 years
	500mL	10 years	1L	4 years
	250mL	3 years	750mL	3 years
			500mL	2 years
Reticulation Systems Cavity infill & footing barriers	500mL	5 years	1L	2 years
Protection of Poles & Fence Posts	500mL	10 years	1.5L	5 years
			1L	4 years
			750mL	3 years
Nest Eradication	500mL	Not applicable	500mL	Not applicable

Note 1: This rate must be used in conjunction with a certified reticulation system that is capable of distributing the Termiticide & Insecticide emulsion according to the product label and the Australian Standard AS 3660 Series.

* The need for retreatment is to be determined as a result of at least an annual inspection, or more frequently in high risk areas, by a qualified Pest Control Operator.

The actual protection will depend on the termite hazard, climate, soil conditions and rate of termiticide used.

TABLE B: CRITICAL COMMENTS for use against Subterranean Termites

SITUATION	CRITICAL COMMENTS
Pre-Construction Barriers Under slabs for protection of new buildings	<ul style="list-style-type: none"> Apply with suitable application equipment to form a complete and continuous chemical barrier (both vertical and horizontal) under the slab. The formation of the barrier may require a combination of conventional open wand application and soil trenching and/or rodding applications. Recommended rod spacing should be between 150 and 300mm, as per soil type. For additional information refer to "CRITICAL APPLICATION DETAILS" on this label and the Australian Standard AS 3660 Series. An external perimeter barrier (both horizontal and vertical) is an essential part of termite protection and must be installed at the completion of the building. Refer to "Perimeter Barriers" below for further details. Chemical barriers that have been disturbed by construction, excavation and/or landscaping activities will need to be reapplied to restore continuity of the barrier.
Pre-Construction Barriers Under suspended floors	<ul style="list-style-type: none"> For areas beneath suspended floors that have inadequate access (eg. less than 400mm clearance), the entire sub-floor area should be treated as a continuous horizontal barrier, which completely abuts an internal vertical barrier around any substructure walls. Ideally, this operation should be done during construction of the building while access is more readily available. For areas beneath suspended floors which have adequate access (eg. more than 400mm clearance), install perimeter barriers around each individual pier, stump, service penetration and substructure walls. An external perimeter barrier (both horizontal and vertical) is an essential part of termite protection and must be installed at the completion of the building. Refer to "Perimeter Barriers" below for further details.
Perimeter Barriers For new and existing buildings	<ul style="list-style-type: none"> Perimeter barriers (both horizontal and vertical, external and, where required, internal or sub-floor) are an essential part of termite protection and must be installed at the completion of the building. Perimeter barriers should be installed around slabs, piers, substructure walls and external penetration points. Apply with suitable application equipment to form a continuous chemical barrier (both vertical and horizontal) around the structure and to a depth reaching to 80mm below the top of the footings, where appropriate. The formation of the barrier may require a combination of several application techniques, including soil trenching and/or rodding and open wand applications. Chemical barriers that have been disturbed by construction, excavation and/or landscaping activities will need to be reapplied to restore continuity of the barrier.
Post-Construction Barriers For the protection of existing buildings	<ul style="list-style-type: none"> Apply with suitable application equipment to form a continuous chemical barrier (both vertical and horizontal) around and under the structure with particular emphasis on known infestation areas. The formation of the barrier may require a combination of several application techniques, including soil rodding, trenching, open wand applications and sub-slab injections. Chemical barriers beneath concrete slabs and paths will require concrete drilling. Recommended drill hole spacings are between 150 and 300mm. To enhance soil distribution use a lateral dispersion tip on the injector and up to 10L of emulsion per linear metre. To ensure formation of a continuous barrier, holes should be drilled no more than 150mm from walls or expansion joints. For areas beneath suspended floors that have inadequate access (eg. less than 400mm clearance), the entire sub-floor area should be treated as a continuous horizontal barrier, which completely abuts an internal vertical barrier around any substructure walls. Otherwise, install perimeter barriers around each individual pier, stump, penetration point and substructure walls. Chemical barriers that have been disturbed by construction, excavation and/or landscaping activities will need to be reapplied to restore continuity of the barrier.
Reticulation Systems Perimeter and/or service penetration treatment only	<ul style="list-style-type: none"> TITAN Bifenthrin 100 Termiticide & Insecticide must be used through a certified reticulation system to form and replenish perimeter barriers around buildings and service penetrations. The system must be installed according to the manufacturer's specifications and be capable of distributing the termiticide emulsion according to the product label and the Australian Standard AS 3660 Series. Perimeter barriers consist of a horizontal barrier abutting a vertical barrier, which must reach down to the top of the footings. Delivery pipes must be placed in such a position to ensure that the requirements for both horizontal and vertical barriers as specified in the Australian Standard AS 3660 Series are met. Special attention must also be afforded to the positioning of the delivery pipes to ensure that the resultant termiticidal barriers are continuous and complete. Apply the prepared termiticide emulsion by pumping through the system according to the manufacturer's specifications. Use a minimum delivery volume of 100L of emulsion per m³ of soil. This equates to a delivery volume of 5L of emulsion per linear metre for a vertical barrier 300mm x 150mm in dimension. Pre-Construction – For use in conjunction with full soil treatment horizontal barriers only: Apply the diluted emulsion through the perimeter reticulation system as specified above. Follow instructions for Pre-Construction horizontal barrier formation.
Reticulation Systems Cavity infill & footing barriers	<ul style="list-style-type: none"> TITAN Bifenthrin 100 Termiticide & Insecticide must be used through a certified reticulation system to form and replenish cavity infill and footing barriers. The system must be installed according to the manufacturer's specifications and be capable of distributing the termiticide emulsion according to the product label and the Australian Standard AS 3660 Series. Delivery pipes must be placed in such a position to ensure that the requirements for both horizontal and vertical barriers as specified in the Australian Standard AS 3660 Series are met. Special attention must also be afforded to the positioning of the delivery pipes to ensure that the resultant termiticidal barriers are continuous and complete. Apply the prepared termiticide emulsion by pumping through the system according to the manufacturer's specifications with a delivery volume of 2L of emulsion per linear metre of delivery pipe. Note: Where this system is to be installed at the pre-construction stage, a full under slab pre-construction barrier, applied by either open wand application or suitably certified reticulation system, is also recommended. The recommended rate of application is 2L of emulsion per liner metre which equates to 2L of emulsion per 0.0068m³ or approximately 7L of sand. Should the volume of fill in the wall cavity deviate from 7L (0.17m x 0.04m x 1m = 0.0068m³) per linear metre of wall cavity, then the amount of TITAN Bifenthrin 100 Termiticide & Insecticide emulsion applied per linear metre of wall cavity should be adjusted accordingly. As a guide, the target bifenthrin loading of treated sand/soil in a cavity infill situation is 110mg/kg South of the Tropic of Capricorn and 220mg/kg North of the Tropic of Capricorn. To facilitate more even distribution of the TITAN Bifenthrin 100 Termiticide & Insecticide emulsion in the wall cavity, ensure that the fill is evenly compacted at the time of installation. To further enhance distribution saturation of the sand/soil in the infill is recommended at the time of treatment.
Protection of Service Poles and Fence Posts	<ul style="list-style-type: none"> Create a continuous termiticide barrier 450mm deep and 150mm wide around the pole or post by soil injection or rodding. For new poles and posts, treat backfill and the bottom of the hole. Use 100L of emulsion per m³ of soil. Regular inspections should be undertaken to determine when and if retreatment is necessary. If disturbance of the barrier has occurred, retreatment of the area affected will be required. Posts and poles may also be drilled and injected with spray solution. Note: For existing poles and posts, it is impractical to treat the full depth and underneath of such poles and posts and therefore the possibility of future termite attack from below the treated area cannot be ruled out.

TABLE B: CRITICAL COMMENTS for use against Subterranean Termites – continued

SITUATION	CRITICAL COMMENTS
Eradication of Termite Nest	<ul style="list-style-type: none"> Locate nest and flood with insecticide emulsion. Trees, poles, posts and stumps containing nests may require drilling prior to treatment with termiticide emulsion. The purpose of drilling is to ensure the termiticide emulsion is distributed throughout the entire nest. Drill holes in live trees should be sealed with an appropriate caulking compound after injection.

Note: The termite barrier provided by this product has a finite life. This together with the recommendation to undertake annual inspections must be stated on the durable notice required by the BCA, B1.3(j)(ii).

NOT TO BE USED FOR ANY PURPOSE, OR IN ANY MANNER, CONTRARY TO THIS LABEL UNLESS AUTHORISED UNDER APPROPRIATE LEGISLATION.

CONDITIONS OF USE BY AUTHORISED PERSONS

The Pest Control Operator must be licensed under State legislation. The Pest Control Operator must notify the site supervisor, if any, and workers who come into contact with uncovered treated soil prior to laying the moisture membrane, to wear appropriate personal protective equipment and to observe re-entry requirements.

(For personal protective equipment, refer to “SAFETY DIRECTIONS” and for re-entry, refer to “PRECAUTIONS AND RE-ENTRY PERIODS” below.)

GENERAL INSTRUCTIONS

Urban Pest Control

TITAN Bifenthrin 100 Termiticide & Insecticide is a powerful knockdown and residual pesticide. Ants, cockroaches, fleas, flies mosquitoes, spiders, ticks and wasps are controlled by direct contact with spray and also by residual action as they come into contact with treated surfaces.

Termites

The use of TITAN Bifenthrin 100 Termiticide & Insecticide will help prevent and control subterranean termite infestations in and around buildings and structures, when used in accordance with the Australian Standard AS 3660 Series, Termite Management. A dilute termiticidal emulsion must be adequately dispersed into the soil to establish a barrier between the building and subterranean termites in the soil. The purpose of a termite barrier is to prevent concealed termite entry into the building.

The biology and behaviour of the termite species involved, should be considered by the Pest Control Operator in determining which control measures are most appropriate to control and prevent termite infestation.

MIXING

Add the required quantity of TITAN Bifenthrin 100 Termiticide & Insecticide to water in the spray tank and mix thoroughly. Maintain agitation during both mixing and application.

To facilitate even application of the termiticide emulsion over the area to be treated, the addition of a marker dye at label rates is recommended. On hard to wet soils, the penetration of the termiticide emulsion may be improved by the addition of a soil surfactant at label rates.

CRITICAL APPLICATION DETAILS

The application of TITAN Bifenthrin 100 Termiticide & Insecticide to form both horizontal and vertical chemical barriers must be in accordance with the Australian Standard AS 3660 Series.

For treatment of new and existing buildings, both horizontal and vertical barriers may be required around and under the building. External perimeter barriers and where required, internal perimeter barriers, are an essential part of this treatment. The purpose of a chemical termite soil barrier is to provide a continuous, no gap, barrier between the building and the termite colony. It is therefore essential that the Pest Control Operator is familiar with the construction details of the building. For further details, refer to the “Horizontal Barrier Treatments” and “Vertical Barrier Treatments” statements in this leaflet and to the Australian Standard AS 3660 Series.

TREATMENTS

Horizontal Barrier:

Use 5L of emulsion per m² of soil. Apply the termiticide emulsion evenly to the soil surface area to ensure the provision of a continuous barrier with no gaps. To minimise drift, use low pressure, high volume spray equipment delivering large coarse droplets. On impervious soils, where the application of 5L/m² would cause excessive run-off, the application volume may be reduced provided the concentration of the emulsion is increased by a corresponding amount. For example, the volume of applied concentrate must remain constant at 25, 50 or 75mL/m² depending on the location and the situation. DO NOT apply emulsion volumes below 2L/m².

In situations where the soil surface is very dry and conditions are conducive to rapid drying, the area to be treated should be moistened prior to the termiticide application.

It is important to note that when applying a horizontal barrier to the perimeter of a building or structure the chemical barrier is deemed to have a depth of 80mm. In situations where the emulsion will not readily wet the soil to the required depth, loosen soil to a depth of 80mm by 150mm wide and apply 1.5L of emulsion per lineal metre.

Vertical Barrier:

To install a vertical barrier use a minimum of 100L of emulsion per m³ of soil. Vertical barriers must be a minimum of 150mm wide, extend down to 80mm below the top of the footing and be complete and continuous. Vertical barriers can be installed by trenching and treating the soil as it is backfilled, by soil rodding or by the use of certified reticulation systems as described in the Australian Standard AS 3660 Series. The preferred method of installing a vertical barrier treatment is either by trenching and treating the soil as it is backfilled or by delivery via a certified reticulation system. When using the soil rodding method to establish a vertical barrier the distance between rod spacings should be as per the following table. To improve soil penetration, the soil should be loosened to a depth of 150mm.

Soil Type	Rod Spacing (mm)
Heavy Clay	150
Clay Loams	200
Loams	250
Sands	300

Perimeter Barrier:

Perimeter barriers consist of horizontal barriers at least 150mm wide adjoining a vertical barrier of at least 150mm in width. A perimeter barrier must completely surround all buildings, pipes, piers and service penetrations. In buildings with suspended floors with greater than 400mm crawl space, perimeter barriers should be installed to surround piers, stumps and service penetrations and completely abut all substructure walls.

To ensure provision of a continuous barrier use a minimum of 100L of emulsion per m³ of soil. This equates to a delivery volume of 5L of emulsion per linear metre for a 300mm vertical barrier, or 10L of emulsion per linear metre for a 600mm vertical barrier.

Termites may gain access behind engaged piers against single brick walls unless the soil is treated on both sides of the wall down to the footing.

Post-Construction Under Slab Treatment:

For concrete slabs, the emulsion needs to be injected through pre-drilled holes through the slab, at intervals between 150mm and 300mm. The following table shows the recommended hole spacing and recommended volume of spray solution required per hole, depending on the soil type.

Soil Type	Hole Spacing (mm)	Litres per hole
Heavy Clay	150	1.5
Clay Loams	200	2
Loams	250	2.5
Sands	300	3

Application equipment used to inject TITAN Bifenthrin 100 Termiticide & Insecticide through pre-drilled holes in an interior situation must be in good working order, free from any leaks and the injector must have tip shut-off to prevent nozzle dripping. Lateral dispersion tips are recommended. Drill holes must be resealed following injection of the TITAN Bifenthrin 100 Termiticide & Insecticide emulsion. The decision and/or need for drilling concrete floor slabs should only be made after a thorough inspection of the building. The degree of termite activity should also be taken into consideration.

Treatment in Conjunction with Physical Barriers:

In situations where the termite protection system is to consist of a combination of both physical and chemical barriers, each certified system must be installed according to the relevant and appropriate product specification and the Australian Standard AS 3660 Series.

Reticulation System:

TITAN Bifenthrin 100 Termiticide & Insecticide can be used through reticulation systems to form horizontal and vertical barriers under and around structures and all service penetrations. The reticulation system must be certified and be capable of distributing the termiticide emulsion according to the product label and the Australian Standard AS 3660 Series.

In situations using reticulation systems to form barriers around the perimeter and/or service penetrations only, a full pre-construction soil applied TITAN Bifenthrin 100 Termiticide & Insecticide horizontal barrier is recommended. It is the responsibility of the builder and all relevant sub-contractors to ensure that all termite barrier systems are installed in accordance with the relevant product installation directions and the Australian Standard AS 3660 Series.

Service requirements:

Service requirements are to be determined as a result of at least an annual inspection by a licensed Pest Control Operator. More frequent inspections may be required in high risk termite areas.

In determining the need for service, factors such as local termite pressure, breaches of the barrier and termiticide longevity should be considered.

Subterranean termites are on occasions capable of bridging termite barriers and therefore regular inspections, as detailed in the Australian Standard AS 4349.3, will significantly increase the probability of detection of termite activity before any damage or costly repairs are required.

Several factors contribute to longevity of the termite treatment and must be considered when evaluating the need for retreatment. The actual protection period will depend on the termite hazard, climate, soil conditions and rate of termiticide used. Refer to Table A for the expected protection periods provided.

PRECAUTIONS AND RE-ENTRY PERIODS

DO NOT spray into the air or directly on humans, pets or animals. Avoid contact with food, food utensils or preparation surfaces.

RE-ENTRY PERIOD

Pre-Construction:

DO NOT allow entry into uncovered treated areas until the spray has dried. When prior entry is necessary, wear cotton overalls buttoned to the neck, wrist and elbow length PVC, neoprene or nitrile gloves and chemical resistant footwear. Clothing must be laundered after each day's use.

Post-Construction and Urban Pest Control:

DO NOT allow people and pets to enter treated areas until the spray has dried. When prior entry is necessary, wear cotton overalls buttoned to the neck, wrist and elbow length PVC, neoprene or nitrile gloves and chemical resistant footwear. Clothing must be laundered after each day's use.

PROTECTION OF PETS AND LIVESTOCK

Before spraying, remove animals and pets from the areas to be treated. Cover or remove any open food or water containers. Cover or remove fish ponds, aquariums etc. before spraying.

PROTECTION OF WILDLIFE, FISH, CRUSTACEANS AND ENVIRONMENT

Dangerous to fish and aquatic organisms. DO NOT contaminate dams, rivers, streams, waterways or drains with product or the used container.

SMALL SPILL MANAGEMENT

Wear appropriate clothing and protective equipment whilst cleaning up small spills (see SAFETY DIRECTIONS). Apply absorbent material such as earth, sand, cat litter or clay granules to the spill. Sweep up material and contain in a refuse vessel for disposal. Dispose of the contaminated material in accordance with STORAGE AND DISPOSAL instructions below or according to Australian Standard AS 2507 – Storage and Handling of Pesticides.

STORAGE AND DISPOSAL

Store in closed, original container in a cool well-ventilated area away from children, animals, food and feedstuffs. DO NOT store for long periods in direct sunlight. DO NOT allow spilled product to enter sewers, gutters or storm water drains, creeks or any other waterways.

Triple or preferably pressure rinse containers before disposal. Add rinsings to spray tank. DO NOT dispose of undiluted chemicals on site. If recycling, replace cap and return clean containers to recycler or designated collection point. If not recycling break, crush or puncture and bury empty containers in a local authority landfill. If no landfill is available, bury the containers below 500mm in a disposal pit specifically marked and set up for this purpose clear of waterways, desirable vegetation and tree roots. Empty containers and product should not be burnt. DO NOT bury waste or surplus product. Dispose of undiluted waste by either dilution, and use according to the Directions for Use, or returning to the point of purchase in the original container for controlled disposal. Dispose of diluted surplus product by using according to the Directions for Use. DO NOT re-use empty container.

SAFETY DIRECTIONS

Poisonous if swallowed. Will damage eyes and will irritate skin. Avoid contact with eyes and skin. DO NOT inhale vapour or spray mist. When opening the container and preparing the spray, wear cotton overalls buttoned to the neck and wrist, a washable hat, elbow-length PVC, neoprene or nitrile gloves, face shield or goggles and chemical resistant footwear. When using prepared spray, wear cotton overalls buttoned to the neck and wrist, a washable hat, elbow-length PVC, neoprene or nitrile gloves, face shield or goggles and chemical resistant footwear. When using in enclosed areas, wear cotton overalls buttoned to the neck and wrist, a washable hat, elbow-length PVC, neoprene or nitrile gloves, face shield or goggles and chemical resistant footwear and half-face respirator with the combined dust and gas cartridge. If clothing becomes contaminated with product or wet with spray, remove clothing immediately. If product or spray on skin, immediately wash area with soap and water. If product in eyes, wash it out immediately with water. After use and before eating, drinking or smoking, wash hands, arms and face thoroughly with soap and water. Thoroughly ventilate treated areas before reoccupying. After each day's use wash gloves, face shield or goggles, respirator (if rubber wash with detergent and warm water) and contaminated clothing.

FIRST AID

If poisoning occurs, contact a doctor or Poisons Information Centre. Phone Australia 13 11 26. If swallowed, DO NOT induce vomiting. Give a glass of water.

MATERIAL SAFETY DATA SHEET

Additional information is listed in the material safety data sheet (MSDS). A material safety data sheet for TITAN Bifenthrin 100 Termiticide & Insecticide is available from TITAN AG Pty Ltd on request. Call Customer Service on (02) 9986 2943 or visit www.titanag.com.au

CONDITIONS OF SALE

TITAN AG Pty Ltd shall not be liable for any loss injury damage or death whether consequential or otherwise whatsoever or howsoever arising whether through negligence or otherwise in connection with the sale supply use or application of this product. The supply of this product is on the express condition that the purchaser does not rely on TITAN AG's skill or judgment in purchasing or using the same and every person dealing with this product does so at his own risk absolutely. No representative of TITAN AG Pty Ltd has any authority to add to or alter these conditions.